

The DFMA software is typically installed as a client application. For floating licenses, the DFMA License Manager utilizing FLEXlm is installed on a Windows network server.

DFMA libraries are installed on the client. Libraries modified with specific company information to be shared among users can be installed and accessed on company networks. Completed analysis files are also typically shared on networks.

Bill of material information can be imported as a text file into the DFA software via the DFA text import wizard. Solid model geometry data can be imported into the DFMA software from STL, IGES and STEP files.

Instead of locking our users into a proprietary format, our data is open so users can have the ability to transparently access their data without needing our application. Our DFMA data is stored in XML files.

### DFMA Network Integration

